

Parameterisable damper actuator for adjusting dampers in technical building installations

- Air damper size up to approx. 4 m²
- Nominal torque 20 Nm
- Nominal voltage AC/DC 24 V
- Control modulating DC (0)2...10 V Variable
- Position feedback DC 2...10 V Variable
- Running time motor 35 s Variable


Technical data

| | | |
|---------------------------|--|---|
| Electrical data | Nominal voltage | AC/DC 24 V |
| | Nominal voltage frequency | 50/60 Hz |
| | Nominal voltage range | AC 19.2...28.8 V / DC 21.6...28.8 V |
| | Power consumption in operation | 4 W |
| | Power consumption in rest position | 1.5 W |
| | Power consumption for wire sizing | 7 VA |
| | Connection supply / control | Cable 1 m, 4 x 0.75 mm ² |
| | Parallel operation | Yes (note the performance data) |
| Functional data | Torque motor | Min. 20 Nm |
| | Torque variable | 25%, 50%, 75% reduced |
| | Positioning signal Y | DC 0...10 V |
| | Positioning signal Y note | Input impedance 100 kΩ |
| | Control signal Y variable | Open-close |
| | Operating range Y | DC 2...10 V |
| | Operating range Y variable | Start point DC 0.5...30 V End point DC 2.5...32 V |
| | Position feedback U | DC 2...10 V |
| | Position feedback U note | Max. 0.5 mA |
| | Position feedback U variable | Start point DC 0.5...8 V End point DC 2.5...10 V |
| | Position accuracy | ±5% |
| | Direction of motion motor | selectable with switch 0 / 1 |
| | Direction of motion note | Y = 0 V: At switch position 0 (ccw rotation) / 1 (cw rotation) |
| | Direction of motion variable | electronically reversible |
| | Manual override | with push-button, can be locked |
| | Angle of rotation | Max. 95° |
| | Angle of rotation note | can be limited on both sides with adjustable mechanical end stops |
| | Running time motor | 35 s / 90° |
| | Motor running time variable | 35...150 s |
| | Adaption setting range | manual |
| | Adaption setting range variable | Automatic adaption whenever the supply voltage is switched on, or manual triggering |
| | Override control | MAX (maximum position) = 100% MIN (minimum position) = 0% ZS (intermediate position, AC only) = 50% |
| Override control variable | MAX = (MIN + 32%)...100% MIN = 0%...(MAX - 32%) ZS = MIN...MAX | |
| Sound power level motor | 55 dB(A) | |
| Spindle driver | Universal spindle clamp reversible 10...20 mm | |
| Position indication | Mechanically, pluggable | |
| Safety | Protection class IEC/EN | III Safety Extra-Low Voltage (SELV) |
| | Protection class UL | UL Class 2 Supply |
| | Degree of protection IEC/EN | IP54 |
| | Degree of protection NEMA/UL | NEMA 2, UL Enclosure Type 2 |
| | EMC | CE according to 2014/30/EU |
| Certification IEC/EN | IEC/EN 60730-1 and IEC/EN 60730-2-14 | |

Technical data

| | | |
|---------------|--|---|
| Safety | Certification UL | cULus according to UL 60730-1A, UL 60730-2-14 and CAN/CSA E60730-1:02 |
| | Mode of operation | Type 1 |
| | Rated impulse voltage supply / control | 0.8 kV |
| | Control pollution degree | 3 |
| | Ambient temperature | -30...50 °C |
| | Non-operating temperature | -40...80 °C |
| | Ambient humidity | 95% r.h., non-condensing |
| | Maintenance | Maintenance-free |
| Weight | Weight | 1.1 kg |


Safety notes



- The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea)water, snow, ice, insolation or aggressive gases interfere directly with the actuator and that is ensured that the ambient conditions remain at any time within the thresholds according to the data sheet.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- Cables must not be removed from the device.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

| | |
|-------------------------------------|--|
| Mode of operation | The actuator is connected with a standard modulating signal of DC 0...10V and drives to the position defined by the positioning signal. Measuring voltage U serves for the electrical display of the damper position 0...100% and as slave control signal for other actuators. |
| Parameterisable actuators | The factory settings cover the most common applications. Single parameters can be modified with the Belimo Service Tools MFT-P or ZTH EU. |
| Simple direct mounting | Simple direct mounting on the damper spindle with an universal spindle clamp, supplied with an anti-rotation device to prevent the actuator from rotating. |
| Manual override | Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked). |
| Adjustable angle of rotation | Adjustable angle of rotation with mechanical end stops. |
| High functional reliability | The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached. |
| Home position | The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%). The actuator then moves into the position defined by the positioning signal. |



Product features

- Adaption and synchronisation** An adaption can be triggered manually by pressing the “Adaption” button or with the PC-Tool. Both mechanical end stops are detected during the adaption (entire setting range).
Automatic synchronisation after pressing the gearbox disengagement button is configured. The synchronisation is in the home position (0%).
The actuator then moves into the position defined by the positioning signal.
A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

Accessories

| | Description | Type |
|--|---|-------------|
| Electrical accessories | Auxiliary switch, add-on, 1 x SPDT | S1A |
| | Auxiliary switch, add-on, 2 x SPDT | S2A |
| | Feedback potentiometer 140 Ohm, add-on | P140A |
| | Feedback potentiometer 140 Ohm, add-on, grey | P140A GR |
| | Feedback potentiometer 200 Ohm, add-on | P200A |
| | Feedback potentiometer 500 Ohm, add-on | P500A |
| | Feedback potentiometer 500 Ohm, add-on, grey | P500A GR |
| | Feedback potentiometer 1 kOhm, add-on | P1000A |
| | Feedback potentiometer 1 kOhm, add-on, grey | P1000A GR |
| | Feedback potentiometer 2.8 kOhm, add-on | P2800A |
| | Feedback potentiometer 2.8 kOhm, add-on, grey | P2800A GR |
| | Feedback potentiometer 5 kOhm, add-on | P5000A |
| | Feedback potentiometer 5 kOhm, add-on, grey | P5000A GR |
| | Feedback potentiometer 10 kOhm, add-on | P10000A |
| | Feedback potentiometer 10 kOhm, add-on, grey | P10000A GR |
| | Signal converter voltage/current, supply AC/DC 24V | Z-UIC |
| | Digital position indicator for front-panel mounting, 0...99%, front mass 72 x 72 mm | ZAD24 |
| | Range controller for wall mounting, adjustable electron. Min./max. angle of rotation limitation | SBG24 |
| | Positioner for wall mounting, range 0...100% | SGA24 |
| | Positioner in a conduit box, range 0...100% | SGE24 |
| Positioner for front-panel mounting, range 0...100% | SGF24 | |
| Positioner for wall mounting, range 0...100% | CRP24-B1 | |
| Connection cable 5 m, A+B: RJ12 6/6, To ZTH/ZIP-USB-MP | ZK1-GEN | |
| Connection cable 5 m, A: RJ11 6/4, B: Free wire end, To ZTH/ZIP-USB-MP | ZK2-GEN | |
| Mechanical accessories | Actuator arm, for standard spindle clamp (reversible) K-SA | AH-20 |
| | Shaft extension 250 mm for CrNi (INOX) | AV12-25-I |
| | Shaft extension 250 mm, for damper spindles Ø 8...25 mm | AV8-25 |
| | Angled ball joint with M8, suitable for damper crank arms KH8 | KG8 |
| | Straight ball joint with M8, suitable for damper crank arms KH8 | KG10A |
| | Damper crank arm, for damper spindles | KH8 |
| | Spindle clamp, one side for NM..A, SM..A | K-ENSA |
| | Spindle clamp, one side for SM..A | K-ENSA-I |
| | Spindle clamp, reversible for SM..A and NMQ.. | K-SA |
| | Universal mounting bracket 180 mm | Z-ARS180 |
| | Universal mounting bracket 230 mm | Z-ARS230 |
| | Angle of rotation limiter, for K-NA | 20334-00001 |
| | Form fit insert 10x10 mm, for NM..A / SM..A | ZF10-NSA |
| | Form fit insert 12x12 mm, for NM..A / SM..A | ZF12-NSA |
| | Form fit insert 15x15 mm | ZF15-NSA |
| | Form fit insert 16x16 mm, for NM..A / SM..A | ZF16-NSA |
| | Mounting kit for linkage operation, SM..A for flat installation | ZG-SMA |

Accessories

| | Description | Type |
|---------------|---|--------|
| | Position indication for LM..A, NM..A, SM..A, GM..A | Z-PI |
| | Base plate extension from SM..A to SM../AM../SMD24R | Z-SMA |
| Service Tools | Description | Type |
| | Service tool for parameterisable and communicative Belimo actuators / VAV controller and HVAC performance devices | ZTH EU |
| | Belimo PC-Tool, software for adjustments and diagnostics | MFT-P |
| | Adapter to Service Tool ZTH | MFT-C |


Electrical installation



- Notes**
- Connection via safety isolating transformer.
 - Parallel connection of other actuators possible. Observe the performance data.

Wiring diagrams

AC/DC 24 V, modulating




Cable colours:
 1 = black
 2 = red
 3 = white
 5 = orange


Functions

Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts





Override control with AC 24 V with rotary switch




Remote control 0...100% with positioner SG..

Minimum limit with positioner SG..




Functions

Follow-up control (position-dependent)




Position indication




(1) Adapting the direction of rotation

Control with 4...20 mA via external resistor



Caution:
The operating range must be set to DC 2...10 V.
The 500 Ω resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V


Functional check




- Procedure**
1. Connect 24V to connections 1 and 2
 2. Disconnect connection 3:
 - with direction of rotation 0: Actuator rotates to the left
 - with direction of rotation 1: Actuator rotates to the right
 3. Short-circuit connections 2 and 3:
 - Actuator runs in opposite direction

Functions for actuators with specific parameters (Parametrisation with PC-Tool necessary)


Override control and limiting with AC 24 V with relay contacts




Control open-close



Control 3-point




Override control and limiting with AC 24 V with rotary switch



1) **Caution:** This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.

Operating controls and indicators



1 Direction of rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press button: Triggers angle of rotation adaptation, followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronising process active

Press button: No function

4 Gear disengagement button

Press button: Gear disengages, motor stops, manual override possible

Release button: Gear engages, synchronisation starts, followed by standard mode

5 Service plug

For connecting parameterisation and service tools

Check power supply connection


2 Off and 3 On Possible wiring error in power supply

Service

Service Tools connection


The actuator can be parameterised by ZTH EU via the service socket.
For an extended parameterisation the PC tool can be connected.

Connection ZTH EU / PC-Tool




Dimensions [mm]

Spindle length



Clamping range



With utilisation of a round spindle made of CrNi (INOX): \varnothing 12...20 mm

Dimensional drawings

